

User Guide

Panasonic KX-TD612 Built in Voice Message

Record Personal Greeting	Dial 7221 then 1 = Extension Outgoing Message
Play Personal Greeting	Dial 7222 then 1 = Extension Outgoing Message
Delete Personal Greeting	Dial 7223 then 1 = Extension Outgoing Message
Record Company Message 1-9 (Extension 201)	Dial 7121 then 1-9 Operator Only
Play Company Message 1-9 (Extension 201)	Dial 7122 then 1-9 Operator Only
Delete Company Message 1-9 (Extension 201)	Dial 7123 then 1-9 Operator Only
Set Call Forward to Voicemail	Dial 710 (2-5) then 725, On-hook (2 = All, 3 = Busy, 4 = No Answer, 5 = Busy/No)
Cancel Call Forward To Voicemail	Dial 7100 then On-hook
To Listen to your Messages	Dial (1) Old/New (2) 723
To Delete your Messages	Dial (1) Old/New (2) 724 (Warning: Deletes <u>all</u> Messages!)
To Transfer a Call Direct to a Mailbox	Dial Transfer, 725 and Extension Number, On-hook. Note: When using the 'Mailbox Transfer' the caller will NOT hear the Mailbox's greeting.



Useful Information

For Technical Assistance or to Report a Fault: Call **0870 891 9000**
For Additional User Information on your Equipment: www.overline.com
For Details or to Order Additional products or Services: Call **0870 891 9000**