

User Guide

Panasonic KXTDA Voice Mail Card



Night Greeting – To record:	From extension 20 Dial *38811 – Speak – AutoDialStore
To record Personal Greeting from any/each extension:	Dial *381 – Speak – Store
To delete Personal Greeting:	Dial *380
To listen to messages:	Press message button 1 To repeat 2 Next message 3 Delete 3 Then 1 (from KXTD7665)
To forward calls to Voicemail:	*7105 591#
To cancel:	Dial *7100